


PHILIPS



Universal counters PM 6611

0046 066 110..1

PM 6613

0046 066 130..1

PM 6614

0046 066 140..1

PM 6615

0046 066 150..1

Ordering number of this manual 9499 460 07711

741015/1/



PHILIPS



PM 6611

9446 066 110..1



PM 6613

9446 066 130..1

Operating manual



PM 6614

9446 066 140..1



PM 6615

9446 066 150..1

IMPORTANT

In correspondence concerning this instrument, please quote the type number and the serial number as given on the type plate on the rear of the instrument.

CONTENTS

General information

I. Introduction	5
II. Technical data	5
III. Accessories	8

Directions for use

IV. Installation	9
1. Mains voltage conversion	9
2. Earthing	9
3. Fuses	9
4. Optional accessories	9
V. Controls and indicators	11
VI. Operation	13

General information

1. Switch on power	13
2. Warm up time	13
3. External frequency standard	13

Measurements

4. CHECK	14
5. FREQUENCY A	14
6. FREQUENCY B	14
7. PERIOD A	14
8. RATIO A/C	14
9. RATIO B/C	14
10. COUNT A	14

List of figures

Figure IV-1. Mains transformer connections	9
Figure VI-1. Front panel PM 6611	16
Figure VI-2. Front panel PM 6613, PM 6614 and PM 6615.	16
Figure VI-3. Rear panel	17
Figure VI-4. Top view	17

I. INTRODUCTION

GENERAL INFORMATION

The counters in the PM 6610-series have frequency ranges from 10 Hz up to 80 MHz, 250 MHz, 520 MHz and 1 GHz respectively for the PM 6611, PM 6613, PM 6614 and PM 6615.

The VHF and UHF counters PM 6613, PM 6614 and PM 6615 offer two different signal inputs for RF- and LF-signals. All models can measure frequency, period, ratio and have a totalizing mode.

Optional accessories such as four different oscillators, a battery unit, a BCD output unit and a D/A converter extend the field of application.

II. TECHNICAL DATA

Properties expressed in numerical values with statement of tolerances are guaranteed. Numerical values without tolerances are intended for information purposes only and indicate the properties of an average instrument. The numerical values hold good for the nominal mains voltage.

A. MEASUREMENTS

Frequency

Range	10 Hz—80 MHz, PM 6611 10 Hz—250 MHz, PM 6613 10 Hz—520 MHz, PM 6614 10 Hz—1000 MHz, PM 6615
Gate times	10 ms, 100 ms, 1 s and 10 s, INPUT A The gate time is multiplied with a prescaling factor if input B is used.
Resolution	100 Hz, 10 Hz, 1 Hz and 0.1 Hz
Accuracy	± 1 count $\pm$ time base error

Single period A

Range	100 ns—100 s
Frequency counted	10 MHz
Time resolution	100 ns
Accuracy	± 1 count $\pm$ trigger error* $\pm$ time base error

* Trigger error is $\pm 3 \times 10^{-3}$ for signals with signal to noise ratio of ≥ 40 dB.

Multiple period A

Range	Sine wave: 10 Hz—10 MHz pulses: 1 Hz—10 MHz
Frequency counted	10 MHz
Number of averagings	$N = 10^2$ and 10^4
Time resolution	$\frac{100 \text{ ns}}{N}$
Accuracy	$\pm 1 \text{ count} \pm \text{trigger error}/N^* \pm \text{time base error}$

Count A

Range	1 to 999999999
Mode	Accumulates pulses during manual start — stop interval
Pulse pair resolution	12 ns

Frequency ratio A/C or B/C

Range	f_A : 10 Hz—80 MHz (All models) f_B : $\begin{cases} 5—250 \text{ MHz, PM 6613} \\ 50—520 \text{ MHz, PM 6614} \\ 50—1000 \text{ MHz, PM 6615} \end{cases}$ f_C : 1 kHz—10 MHz (All models)
Multiplier	$N = 10^2$ and 10^4
Accuracy	$\pm 1 \text{ count} \pm \text{trigger error}^* \text{ of } f_C/N$

Check

10 MHz internally applied to channel A
Any measuring function may be selected

Auxiliary functions

Reset	Pushing "RESET" resets the counter. Releasing "RESET" starts new measurement
Start/Stop	In function "COUNT A" the gate time is manually controlled by push-button "START/STOP". The memory is automatically switched off.
Display time	Continuously variable 0.2—5 s and infinite if display time knob is pulled
Stand by	The switch is combined with display time control. Position "STAND BY" keeps an oven oscillator heated.
Memory	Switchable by push-button "MEMORY"

B. INPUT CHARACTERISTICS**Input A**

Range	10 Hz—80 MHz full range, 10 Hz—100 kHz when low-pass filter is selected by push-button "< 100 kHz"
Sensitivity	Sine wave: $10 \text{ mV}_{\text{rms}}$, 6 dB down at 10 Hz pulses: $30 \text{ mV}_{\text{p-p}}$ for pulse width $\geq 6 \text{ ns}$ and rise time $\leq 1 \text{ ms}$
Impedance	$1 \text{ M}\Omega // 25 \text{ pF}$
Coupling	AC
Attenuation	$\times 1$, $\times 20$ and continuously variable
Trigger mode (level)	Pos.pulse () and neg.pulse () on leading edge and zero crossing ()
Safe overload	
Attenuation $\times 1$	max. 250 V DC or $230 \text{ V}_{\text{rms}} \leq 440 \text{ Hz}$ > 440 Hz : falling to $12 \text{ V}_{\text{rms}}$ at > 1 MHz
Attenuation $\times 20$	max. 250 V DC or $230 \text{ V}_{\text{rms}}$

* Trigger error is $\pm 3 \times 10^{-3}$ for signals with signal to noise ratio of $\geq 40 \text{ dB}$.

Input B (Not present in PM 6611)	<i>PM 6613</i>	<i>PM 6614</i>	<i>PM 6615</i>
Frequency range	5—250 MHz	50—520 MHz	50—1000 MHz
Dynamic input voltage range	10 mV _{rms} —12 V _{rms}	10 mV _{rms} —12 V _{rms}	10 mV _{rms} —12 V _{rms} (may be 3 dB down at 1 GHz)
Impedance	50 Ω	50 Ω	50 Ω
VSWR	< 2	< 2	< 2
Coupling	AC	AC	AC
Attenuation	by automatic PIN diode attenuator, maximum 62 dB.		
Prescaling factor	4	8	16
Safe overload	12 V _{rms}	12 V _{rms}	12 V _{rms}

Input C (rear)

Range	1 kHz—10 MHz
Sensitivity	500 mV _{rms}
Coupling	AC
Impedance	$\approx 10\text{ k}\Omega$
Safe overload	50 V _{rms}

Ext. oscillator

Via Input C. Internally selected by a jumper

C. OUTPUT CHARACTERISTICS

10 MHz OUT

Output frequency	Internal oscillator frequency (10 MHz)
Signal level	$\approx 1\text{ V}_{\text{rms}}$ (open circuit)
Output impedance	Approximately 200 Ω (short-circuit proof)
Coupling	AC

Display

9 digits
In-plane 7 segment gas discharge display with decimal-point indication

Gate lamp

Indicates that main gate is open and counting takes place. In stand-by position, the Gate lamp indicates that mains or battery voltage is connected

D. GENERAL CHARACTERISTICS

Oscillator

See section Accessories, 2.1. and relevant manual.

Supply

By mains	100—130 V or 200—260 V, 50 to 400 Hz, 15—25 VA
By external battery	12 to 24 V, 7.5 to 11 W
By internal battery option	PM 9673

Environmental characteristics

Temperature

Storage	—40°C to +70°C —40°C to +50°C (With battery option PM 9673)
---------	--

Operating	0°C to +50°C (0°C to +40°C with battery option PM 9673)
-----------	--

Mains interference:

Below CISPR

Altitude	5000 m operating 15000 m storage
Humidity	Max. 90% RH (50°C)
Shock	Meets the requirements of the IEC68 Eb recommendations
Vibration	Meets the requirements of the IEC68F recommendations

Dimensions

Width	210 mm
Height	89 mm
Depth	325 mm

Weight	Approx. 2.8 kg
--------	----------------

III. ACCESSORIES

1. Standard accessories supplied with the instrument

- 1 mains cable
- 1 manual
- 1 1.6 A fuse, fast action
- 1 "115 V" label

PM 9584 Resistive mixing piece, 50 Ω , 3 BNC sockets

PM 9346 Active-probe power supply

2. Accessories to be ordered separately

2.1. Oscillators

- PM 9677 Standard oscillator
- PM 9678 TCXO
- PM 9679 Oven-enclosed oscillator 1×10^{-7} /month
- PM 9690 Oven-enclosed oscillator 1.5×10^{-9} /24 h.

2.4. Coaxial cables

- PM 9074 50 Ω , BNC to BNC, length 1 m
- PM 9588 Set of 50 Ω cables, BNC to BNC:
 - 5 cables, length 20.7 cm
 - 4 cables, length 40.5 cm
 - 3 cables, length 60.3 cm
 - 3 cables, length 198.6 cm

2.2. Output interface units

- PM 9674 BCD output unit
- PM 9675 D/A converter

2.5. Mains cable

- PM 9011 3-core detachable mains cable

2.6. Rack mount adapter

- PM 9669 19" rack mount adapter

2.3. Input interface accessories

- PM 9351 Passive measuring probe 10 M Ω / 11 pF
220 MHz, attenuation 10 $\times$
- PM 9353 FET probe, 1M Ω /3.5F, 220 MHz

2.7. Battery unit

- PM 9673 Internal battery unit

2.8. Carrying case

- PM 9672 Carrying case for the instrument

IV. INSTALLATION

1. Mains voltage conversion

The instrument can be converted into two mains voltage ranges 100—130 V and 200—260 V. The frequency range is 50 to 400 Hz. At delivery the instrument is set to the 200 to 260 V range.

When changing to the 100 to 130 V range the connections of the mains transformer should be changed as shown in figure IV-1, and the label "230 V" covered with the "115 V" label supplied.




Figure IV-1. Mains transformer connections

2. Earthing

The local safety regulations prescribe how the instrument should be earthed. Two ways are possible:

1. Via the protective earth terminal at the rear panel.
2. Via the three core mains cable plugged into an outlet with protective earth contact.

NOTE: Use only **one** of these alternatives to avoid hum!

3. Fuses

A thermal fuse on the mains transformer and a 1.6 A fuse, fast action, on unit U1 are protecting the power supply. Refer to figure VI-4.

4. Optional accessories

Refer to installation instruction given in manual for each type number.

V. CONTROLS, INDICATORS AND CONNECTORS

Refer to figures VI-1 to VI-4. on fold-out page.

- 1 DISPLAY TIME**

Sets display time between 0.2 and 5 s.
 Infinite display time when knob is pulled.
 With switch set to position STAND BY the counter is turned off except the oven oscillator.
WARNING: Primary voltage of power supply is on!
- 2 GATE**

Lamp indicating that the main gate is open and that counting takes place.
 With DISPLAY TIME knob set to position STAND BY the GATE lamp is on permanently indicating that the oven oscillator is on.
- 3 SENSITIVITY**

Sensitivity control for input A. When pushed, this control provides continuous setting of the sensitivity between approximately 4 V and 200 mV. With knob pulled the sensitivity can be set between 220 mV and 10 mV.
- 4** 

When measuring signals at input A with duty factor ≤ 0.5 , this push-button must be depressed to obtain reliable triggering.
- 5** 5—250 MHz, PM 6613
 50—520 MHz, PM 6614
 50 MHz—1 GHz, PM 6615

Turns on channel B when depressed.
 Not present in PM 6611.
- 6** 

When measuring signals at input A with duty factor ≥ 0.5 this push-button must be depressed to obtain reliable triggering.
- 7** 

When measuring signals at input A with duty factor ≈ 0.5 this push-button must be depressed to obtain reliable triggering.
- 8 B**

Input B. Signal input for FREQUENCY or RATIO measurement. Frequency range:
 PM 6613, 5 MHz to 250 MHz
 PM 6614, 50 MHz to 520 MHz
 PM 6615, 50 MHz to 1 GHz
 Not present in PM 6611.
- 9 A**

Input A. Signal input for COUNT, FREQUENCY, PERIOD and RATIO measurement. Frequency range 10 Hz to 80 MHz.
- 10** $< 100 \text{ kHz}$


Low-pass filter. When measuring noisy signals at input A with duty factor ≈ 0.5 and frequency $< 100 \text{ kHz}$ triggering is improved by depressing this push-button.
- 11 Function selector**
 COUNT A

Sets counter to add the pulses at input A in the time interval between depressing and releasing the START/STOP push-button.

	FREQUENCY	Sets counter to measure frequency. MHz and kHz are measuring units related to the display read-out. 100 Hz, 10 Hz, 1 Hz and 0.1 Hz is the resolution of the least significant digit.
	PERIOD A	Sets counter to measure period at input A. μs is the measuring unit related to the display read out. n=1, n=10² and n=10⁴ indicates the number of periods being measured.
	RATIO A/C and B/C	Sets counter to measure ratio between signals applied to inputs A and C or B and C. n=10² and n=10⁴ are division factors for the input signal at input C, $\frac{B/C}{n} \text{ or } \frac{A/C}{n}$
12	MEMORY START/STOP	In released position the measurement information is stored until next measurement cycle is completed. Depressed button makes display follow decade counters continuously. In COUNT A mode, start/stop operation.
13	RESET	Resets decade counter and display to zero.
14		Rear panel Mains input.
15	INT.BATT.OFF MAINS/EXT.BATT.	Turns the internal battery off. The mains or the external battery is the power source for the instrument. Internal battery is charged when mains cable is connected.
15	INT.BATT.ON	Sets power supply to be fed from the internal battery. Turns the mains or the external battery off.
16	INPUT C	Input C. Signal input for external time base signal 1 kHz to 10 MHz and RATIO measurement.
17	10 MHz OUT	Output for the internal oscillator signal.
18	BCD	Input connector for BCD unit.
19		Chassis ground.
20	-	Minus-pole connection for external battery.
21	+	Plus-pole connection for external battery.
22	INT.STD/EXT.STD	Internal switch and connector Sets counter to operate with either internal or external clock oscillator.
23		Connector for D/A converter and BCD unit.

VI. OPERATION

Figures VI-1 to VI-4.

General Information

1. Switch on power

1.1. Mains

Before connecting the counter to the mains check that the mains transformer is wired for the local mains voltage. Refer to chapter IV; INSTALLATION.

Set switch MAINS EXT.BATT./INT.BATT.ON to position MAINS EXT.BATT. ⑮.

Connect mains cable to the counter at ⑭.

Turn DISPLAY TIME control ① to ON. Check that GATE lamp ② and display are on, indicating that power is on.

1.2. External battery

Set switch MAINS EXT. BATTERY/INT. BATT. ON ⑮ to position MAINS EXT.BATTERY.

Connect the cables from the external battery to sockets EXT.BATT. 12—24 V “+” ⑳ and “—” ㉑.

Check that GATE lamp ② and display are on, indicating that power is on.

1.3. Internal battery PM 9673

Set switch MAINS EXT. BATTERY/INT. BATTERY ON ⑮ to position INT.BATTERY ON.

Check that GATE lamp ② and display lights indicating that power is on. Blinking display indicates low volt-

ages. Refer to manual PM 9673 for charging instructions.

2. Warm up time

The warm up time from the moment of mains connection is less than 7 minutes to an oscillator error of less than 10^{-7} for instrument equipped with the oven-enclosed oscillators PM 9679 or PM 9690. Instruments equipped with the oscillators PM 9677 or PM 9678 (TCXO) are ready for use at the moment of mains connection. Normally the instrument is switched on from the STAND BY ① position. If so, no warm up time is needed, irrespective of which oscillator is employed.

3. External frequency standards

House standards or other frequency standards can be used instead of the internal 10 MHz oscillator. If a time resolution of 100 ns is required, 10 MHz must be used.

When using 1 MHz instead of 10 MHz the decimal point must be shifted one step to the left to interpret the display correctly. To set the counter to external standard the top cover must be removed and jumper SK 131 ㉒ set to position EXT.

Measurements

4. CHECK

1. Depress the two CHECK push-buttons ⑦ ⑩.
2. Set DISPLAY TIME ① to mid-position
3. Rotate switch ⑪ and read display value as follows:

Function	Read (± 1 digit)
FREQ 100 Hz	10.000
FREQ 10 Hz	10.00000
FREQ 1 Hz	10000.000
FREQ 0.1 Hz	10000.0000
PERIOD $n = 1$	
PERIOD $n = 10^2$	0.100
PERIOD $n = 10^4$	0.10000

4. Set switch ⑪ to position COUNT A.
5. Depress START/STOP push-button ⑫: the counter will start totalizing the input pulses and the display will follow the counting continuously until push-button START/STOP ⑫ is released again.

5. FREQ. A

1. Set DISPLAY TIME ① to mid position.
2. Set function selector ⑪ to any of the four frequency positions that corresponds to the desired resolution of the measurement.
3. Connect the signal to be measured to input A ⑨.
4. Match the input of the counter to the frequency and dutyfactor of the signal to be measured by depressing any of push-buttons ④ ⑥ ⑦ ⑩.
5. Adjust SENSITIVITY control ③ for stable display read-out.

6. FREQ. B (not present in PM 6611)

1. Set DISPLAY TIME ① to mid position.
2. Turn on channel B by depressing the push-button ⑤.
3. Set function selector ⑪ to any of the four frequency positions that corresponds to the desired resolution of the measurement.
4. Connect the signal to be measured to input B ⑧.

7. PERIOD A

1. Set function switch ⑪ to any of the three PERIOD A positions depending on the desired number of periods to be measured.
2. Match the input of the counter to the frequency and dutyfactor of the signal to be measured by depressing any of the push-buttons ④ ⑥ ⑦ ⑩.

8. RATIO A/C*

1. Set function switch ⑪ to any of the two RATIO positions depending on the desired number of decimals of the display read-out.
2. Set DISPLAY TIME ① to mid position.
3. Connect the signal with the highest frequency to input A ⑨.
4. Match the input of the counter to the frequency and duty factor of the signal to be measured by depressing any of the push-buttons ④ ⑥ ⑦ ⑩.
5. Connect the signal with the lowest frequency to input C ⑬.
6. Adjust SENSITIVITY control ③ for stable display read-out.

9. RATIO B/C* (not present in PM 6611)

1. Set function switch ⑪ to any of the two RATIO positions depending on the desired number of decimals of the display read-out.
2. Set DISPLAY TIME ① to mid-position.
3. Connect the signal with the highest frequency to input B ⑧.
4. Turn on channel B by depressing the push-button ⑤.
5. Connect the signal with the lowest frequency to input C ⑬.

10. TOTALIZE (COUNT A)

1. Set function switch ⑪ to position COUNT A.
2. Connect the signal to be measured to input A ⑨.
3. Match the input of the counter to the frequency and duty factor of the signal to be measured by depressing any of the push-buttons ④ ⑥ ⑦ ⑩.
4. Set DISPLAY TIME ① to mid position.
5. Depress START/STOP push-button ⑫.
6. When depressing the START/STOP push-button ⑫ the counter will start totalizing the input pulses until push-button START/STOP ⑫ is released again. The display will show the number of pulses counted in the time interval between depressing and releasing the START/STOP push-button ⑫.


* NOTE

Multiplier factors 10^5 , 10^6 , 10^7 and 10^8 are possible in the frequency mode by using input C as the external time base reference input.
(set the internal jumper switch ⑫ to EXT.)
The decimal point is then incorrectly positioned.


Sales and service all over the world

Argentina: Philips Argentina S.A., Casilla Correo 3479, Buenos Aires; tel. T.E. 70, 7741 al 7749	Guatemala S.A.: Apartado Postal 238, Guatemala City; tel. 64857	Paraguay: Philips del Paraguay S.A., Casilla de Correo 605, Asuncion; tel. 8045-5536-6666
Australia: Philips Electrical Pty Ltd., Philips House, 69-79 Clarence Street, Box 2703 G.P.O., Sydney; tel. 2.0223	Hellas: Philips S.A. Hellénique, B.P. 153, Athens; tel. 230476	Perú: Philips Peruana S.A., Apartado Postal 1841, Lima; tel. 326070
België/Belgique: M.B.L.E., Philips Bedrijfs-apparaatuur, 80 Rue des Deux Gares, Bruxelles; tel. 230000	Hong Kong: Philips Hong Kong Ltd., P.O.B. 2108, St. George's Building, 21st floor, Hong Kong; tel. H-249246	Philippines: Electronic Development & Application Center, 2246 Pasong Tamo Street, P.O.B. 911, Makati Commercial Center, Makati Rizal D-708; tel. 889453 to 889456
Bolivia: Philips Sudamericana, Casilla 1609, La Paz; tel. 5270-5664	India: Philips India Ltd., Shivsagar Estate, Block "A", Dr. Annie Besant Road, P.O.B. 6598, Worli, Bombay 18; tel. 370071	Portugal: Philips Portuguesa S.A.R.L., Rua Joaquim Antonio d'Aquiar 66, Lisboa; tel. 683121/9
Brasil: S.A. Philips Do Brasil, Inbelsa Division; Avenida Paulista 2163; P.O. Box 8681, Sao Paulo S.P.; tel. 81-2161	Indonesia: P. T. Philips Development Corporation, Djalan Proklamasi 33, P.O.B. 2287, Djakarta; tel. 51985-51986	Republique du Zaïre: Philips du Zaïre S.C.R.L., 137, Boulevard du 30 Juin, B.P. 1798, Kinshasa
Burundi: Philips S.A.R.L., Avenue de Grèce, B.P. 900, Bujumbura	Iran: Philips Iran Ltd., P.O.B. 1297, Teheran; tel. 48344-68344	Rwanda: Philips Rwanda S.A.R.L., B.P. 449, Kigali
Canada: Philips Electronic Industries Ltd., Electronic Equipment Division, Philips House, 116 Vanderhoof Avenue, Toronto 17 (Ontario); tel. 425-5161	Island: Heimilistaeki SF, Saetún 8, Reykjavik; tel. 24000	Schweiz-Suisse-Svizzera: Philips A.G., Binzstrasse 38, Postfach 8027, Zürich; tel. 051-442211
Chile: Philips Chiléna S.A., Casilla 2687, Santiago de Chile; tel. 35081	Islas Canarias: Philips Ibérica S.A.E., Triana 132, Las Palmas; Casilla 39-41, Santa Cruz de Tenerife	Singapore: Electronic Supplies (Singapore) Private Ltd. P.O. Box 4029, Singapore 21
Colombia: Industrias Philips de Colombia S.A., Calle 13 no. 51-03, Apartado Nacional 1505, Bogota; tel. 473640	Italia: Philips S.p.A., Sezione PIT; Via Le Elvezia 2, 20052 Monza; tel. (039) 361-441; telex 35290	South Africa: South African Philips (Pty) Ltd., P.O.B. 7703, 2, Herb Street, New Doornfontein, Johannesburg; tel. 24-0531
Costa Rica: Philips de Costa Rica Ltd., Apartado Postal 4325, San José; tel. 210111	Kenya: Philips (Kenya) Ltd., P.O.B. 30554, Nairobi; tel. 29981	Suomi: Oy Philips Ab, Postboks 10255, Helsingki 10; tel. 10915
Danmark: Philips Elektronik Systemer A/S Afd. Industri & Forskning; Strandlodsvej 4 2300-København S; Tel (0127) AS 2222; telex 27045	Malaysia: Electronic Supplies (Malaysia) Sdn Bhd. P.O. Box 332, Kuala Lumpur; tel. 564173	Sverige: Svenska A.B. Philips, Fack, Lidingövägen 50, Stockholm 27; tel. 08/635000
Deutschland (Bundesrepublik): Philips Elektronik Industrie GmbH, Röntgenstrasse 22, Postfach 630111, 2 Hamburg 63; tel. 501031	Mexico: Philips Comercial S.A. de C.V., Uruapan 7, Apdo 24-328, Mexico 7 D.F.; tel. 25-15-40	Taiwan: Yung Kang Trading Co. Ltd., San Min Building, 1st Floor, 57-1 Chung Shan N Road, 2 Section, P.O.B. 1467, Taipei; tel. 577281
Ecuador: Philips Ecuador S.A., Casilla 343, Quito; tel. 239080	Nederland: Philips Nederland B.V., Boschdijk, Gebouw VB, Eindhoven; tel. 793333	Tanzania: Philips (Tanzania) Ltd., p/a P.O.B. 30554, Nairobi, Kenya
Eire: Philips Electrical (Ireland) Ltd., Newstead, Clonskeagh, Dublin 14; tel. 976611	Ned. Antillen: N.V. Philips Antillana, Postbus 523, Willemstad; tel. Curaçao 36222-35464	Thailand: Philips Thailand Ltd., 283, Silom Road, Bangkok; tel. 36980, 36984-9
El Salvador: Philips de El Salvador, Apartado Postal 865, San Salvador; tel. 217441	New Zealand: Philips Electronical Industries (N.Z.) Ltd., Professional and Industrial Division, 70-72 Kingsford Smith Street, P.O.B. 2097, Lyall Bay, Wellington; tel. 73-156	Türkiye: Türk Philips Ticaret A.S., Posta Kutusu 504, Istanbul; tel. 453250
España: Philips Ibérica S.A.E., Avenida de America, Apartado 2065, Madrid 17; tel. 2462200	Nigeria: Philips (Nigeria) Ltd., Philips House, 6 Ijora Causeway, P.O.B. 1921, Lagos; tel. 45414/7	Uruguay: Philips de Uruguay, Avda Uruguay 1287, Montevideo; tel. 956 41-2-3-4
Ethiopia: Philips Ethiopia (Priv. Ltd. Co.), P.O.B. 2565; Cunningham Street, Addis Ababa; tel. 48300	Nippon: Nihon Philips Corporation, P.O.B. 13, Trade Center, Tokyo 105; tel. (03) 435-5211	U.S.A.: Test and Measuring Instruments Inc.; 224 Duffy Avenue, Hicksville, L.I., N.Y. 11802; tel. (516) 433-8800; telex no. 510-221-1839
France: Philips Industrie, Division de la S.A. Philips Industrielle et Commerciale 105, Rue de Paris, 93 002 Bobigny; tel. 84527-09	Norge: Norsk A.S. Philips, Postboks 5040, Oslo; tel. 463890	Venezuela: C.A. Philips Venezolana, Apartado Postal 1167, Caracas; tel. 360511
Ghana: Philips (Ghana) Ltd., P.O.B. M 14, Accra; tel. 66019	Österreich: Oesterreichische Philips Industrie GmbH, Abteilung Industrie Elektronik, Triesterstrasse 64, A-1101 Wien; tel. (0222) 645511/31	Zambia: Philips Electrical Ltd., Professional Equipment Division, P.O.B. 553 Kitwe; tel. 2526/7/8; Lusaka P.O. Box 1878
Great Britain: Pye Unicam Ltd., York Street, Cambridge; tel. (0223) 58866	Pakistan: Philips Electrical Co. of Pakistan Ltd., El-Markaz, M.A. Jinnah Road, P.O.B. 7101, Karachi; tel. 70071	730101
Guatemala: Compañía Comercial Philips de		



For countries not listed and for information on changes of address:
N.V. Philips
Test and Measuring Instruments Dept.
Eindhoven - Netherlands



Block diagram




Circuit diagram 80 MHz input amplifier





MODE	PINS CONNECTED	
	WAFER 2	WAFER 3
COUNT A	1-2	1-3-10
FREQ A	100 Hz	2-3-4-10-12
	10 Hz	1-4-5-10
	1 Hz	2-5-6-10
	0.1 Hz	6-10
PERIOD A	1-5; 3-6-7	8-10
	1-8; 3-7	7-8-9-10
	1-8-9; 3-10	9-10
	1-8-9; 3-10	7-10-11
RATIO A/B or B/C	1-9-11; 3-10	7-10-11
	1-11-12	10-11


Circuit diagram time base divider



Circuit board. Unit U2 PM 6613.








Circuit diagram. Unit U2 PM 6614.

[illegible]

Circuit board soldering side unit U2 PM 6615.



Circuit diagram unit U2 PM 6615.

